



43250 Christy Street
 Fremont, CA 94538
 Phone: +1 (510) 498-7900
sales@starmicrowave.com

PART NUMBER	DESCRIPTION
200490	EX-5r Terminal, RoHS
200496	EX-5r-c Terminal, RoHS
200518	EX-2.4i Terminal
200528	EX-2.4i Terminal, RoHS
200528	Exalt 2.4 GHz IDU 4xT1/E1+10/100BT Terminal with AC Adapter
200529	EX-5i Terminal, RoHS
200530	EX-2.4i-16 Terminal, RoHS
200531	EX-5i-16 Terminal, RoHS
200675	EX-5i 4E1/T1, Terminal ROHS
200682	EX-5i - 16E1/T1, Terminal ROHS
200839	EX-4.9i 4E1/T1, Terminal
200840	EX-4.9i Terminal, RoHS
200842	EX-4.9r-c Terminal, RoHS
201006	EX-5r IP Terminal, RoHS
201016	EX-5r-c IP Terminal, RoHS
201133	EX-5i-DS3 Terminal, RoHS
201304	EX-4.9r Terminal, RoHS
201529	EX-s-16 IDU, RoHS
201535	EX-s 4-100F, Terminal, Exalt, RoHS
201563	EX-5i Lite Terminal, RoHS
201655	EX-4.9r v2 Terminal, RoHS
201656	EX-4.9r-c RoHS
201657	EX-5r v2, Terminal, Exalt, RoHS
201658	EX-5r-c v2, Terminal RoHS
201659	EX-5r GigE
201660	EX-5r-C GigE
201704	EX-5-rc IPv2 Terminal
201908	EX-5i-16 Korea, Terminal, Exalt, ROHS
202369	EX-5r v3 Terminal
202416	EX-5r-c Lite RoHS
202423	EX-5r Lite
202493	EX-6i-DS3 GigE LB LP TYPE II, Terminal, Exalt
202501	EX-6i-DS3-GigE Radio Terminal
202518	EX-2.4i Lite IDU terminal
202561	EX-i Series GigE Monitored Hot Standby (MHS) Kit
202561	Diplexer Filter H/L 6U B3 (ID#111I - 112) - (6645-6715 -MHz/ 6805-6875 MHz)
202588	EX-6i-DS3-GigE 6U, 27dBm 1+0 terminal
202600	EX-6i-DS3-GigE Radio Terminal
203179	ExtendAir AC Power Kit
203218	EX-s Series GigE DS3/8-1000F (Non Fan), Terminal, Exalt, RoHS
203382	EX-4.5r-C GigE
203385	EX-i FDD MHS
203387	ASSY, DS3 MHS PANEL



43250 Christy Street
 Fremont, CA 94538
 Phone: +1 (510) 498-7900
sales@starmicrowave.com

PART NUMBER	DESCRIPTION
203427	EX-4.5r GigE Terminal, Exalt, RoHS
203519	ExtendAir r5000 (1x10/100BaseT), Terminal, Exalt
203520	ExtendAir r5005 (3x10/100BaseT), Terminal, Exalt
203521	ExtendAir r5010 (10/100BaseT+4T1/E1), Terminal, Exalt
203522	ExtendAir rc5000 (1x10/100BaseT), Terminal, Exalt
203523	ExtendAir rc5005 (3x10/100BaseT), Terminal, Exalt
203524	Exalt ExtendAir 5 GHz Triband Outdoor Radio, 27Mbps+4T1, Expandable to 160Mbps, Connectorized
203537	Mounting kit for ExtendAir rc models with external antenna
203594	EX-s DS3/8-1000F, Terminal
203609	s-Series GigE DS3/16-1000F IDU
203612	EX-s 16-1000E, Terminal, Exalt
203723	ExploreAir LR rc11150 2 x 10/100/1000BaseT
203750	EX-s 1000F, Terminal
203862	EX-s 8-1000F
203908	EX-11i-DS3-GigE
203941	Power Supply
204016	EX-6i-DS3-GigE 6L, 30dBm 1.5+0 terminal
204056	ExtendAir r5015
204061	ExtendAir rc5015 (10/100BaseT+2T1/E1), Terminal, Exalt
204088	PCB Assembly, 18GHz ExtremeAir RF Board
204094	EX-6i-DS3 GigE LB HP TYPE II, Terminal
204097	EX-6i-DS3 GigE HB HP TYPE II, Terminal
204230	EX-6i-4DS3-GigE 6L
204233	EX-6i-OC3 GigE LB HP TYPE I, Terminal
204239	EX-11i-OC3 GigE TYPE I, Terminal, Exalt
204242	EX-11i-DS3-GigE Radio Terminal
204263	ExtendAir rc4900 (1x10/100BaseT), Terminal, Exalt
204265	EX-s 2OC3/4-1000F, Terminal, Exalt
204266	EX-s 2STM1/4-1000E, Terminal
204276	EX-s 8-1000E, Terminal
204280	ExtendAir rc11000 (1x10/100BaseT) Terminal, FCC
204281	ExtendAir rc13000 ITU/ETSI
204283	ExtendAir rc18000 (1x10/100BaseT) Terminal, FCC
204284	ExtendAir rc23000 (1x10/100BaseT) Terminal, FCC
204285	ExtendAir rc24000 (1x10/100BaseT)
204337	EX-s Series GigE 4DS3/4-1000F
204382	ExtendAir r4900 (1x10/100BaseT), Terminal, Exalt
204401	ExtendAir r4905, 4.9 GHz Terminal
204406	ExtendAir r4910 terminal (10/100BaseT +4xT1/E1), Terminal, Exalt
204411	ExtendAir rc4905 terminal (3x10/100BaseT)
204416	ExtendAir rc4910 terminal 10X/100BaseT+4XT1/E
204440	ExtendAir rc11005 (3x10/100BaseT) Terminal, FCC
204444	ExtendAir rc11010 (10/100BaseT+4T1/E1) Terminal, FCC



43250 Christy Street
 Fremont, CA 94538
 Phone: +1 (510) 498-7900
sales@starmicrowave.com

PART NUMBER	DESCRIPTION
204448	ExtendAir rc18005 (3x10/100BaseT) Terminal, FCC
204452	ExtendAir rc18010 FCC
204460	ExtendAir rc23010 (10/100BaseT+4T1/E1) Terminal, FCC
204579	SCD, DIPLXR, 21.200-23.608 GHz, 1232 MHz T/R, ExtendAir, ETSI, ROHS
204731	ExploreAir rc23100 Terminal
204762	ExtendAir r5005 (3x10/100BaseT), Terminal, Cisco -A
204868	ExploreAir rc18100 FCC 1xPoE TR1560 MHz
204869	ExploreAir rc11100 Terminal, FCC
204895	ExploreAir rc18100 Terminal, ETSI
204922	ExtendAir r5005 (3x10/100BaseT), Terminal, Cisco -E
204942	ExploreAir rc18110 Terminal, FCC
205008	ExploreAir rc13100 Terminal, ETSI
205015	ExtendAir rc23000 23 GHz ITU/ETSI 1x10/100BaseT PoE, 25 Mbps expandable to 100 Mbps, Band 1 Low
205060	6Ghz IDU terminal, lower band 5.925-6.425Ghz)
205107	EX-s 1000E, Terminal
205151	ExtremeAir rc18200 Terminal, FCC
205160	ExploreAir rc11105 Terminal
205228	ExtremeAir rc23200 Terminal, FCC
205339	ExploreAir rc23105 Terminal, FCC
205457	ExploreAir rc18105 Terminal, FCC
205483	ExploreAir rc23110
205493	ExploreAir rc11100 Terminal 1xPoE, ETSI / FCC
205495	ExploreAir rc11105 Terminal, 3xPoE 1000 BASE-T, ETSI / FCC
205497	ExploreAir rc11110 Terminal
205502	ExploreAir rc13110 Terminal, ETSI
205508	ExploreAir rc15100 Terminal, ETSI
205847	EX-11i GigE TYPE I, Terminal
205848	EX-11i GigE TYPE II, Terminal
205866	ExploreAir rc5100 Terminal
205924	EX-5/6i-DS3 GigE LB LP TYPE II, Terminal
205949	DIPLXR, 10.700-11.700 GHz (SB1) 490/500/530 MHz T/R, ExploreAir HP/LR
205959	EX-6i GigE LB TYPE I, Terminal
205960	EX-6i GigE LB TYPE II
205961	EX-6i GigE HB TYPE I, Terminal
205962	EX-6i GigE HB TYPE II, Terminal
205988	ExtendAir rc4005 terminal (3x10/100BaseT), Terminal
206050	ExtremeAir rc11200 FCC/ITU TR490/500 MHz
206051	ExtremeAir rc11205 Terminal, FCC
206060	ExploreAir rc11100 HP (1xPoE) Terminal, FCC/ETSI
206166	EX-6i-OC3 GigE LB HP TYPE I, Terminal
206181	ExtendAir r4005 terminal, (3X 10/100 BaseT) Terminal, Exalt
206188	ExploreAir rc28100 Terminal
206195	ExtendAir rc4005 (3x10/100BaseT), Terminal, Exalt



43250 Christy Street
 Fremont, CA 94538
 Phone: +1 (510) 498-7900
sales@starmicrowave.com

PART NUMBER	DESCRIPTION
206209	Label, BarTender, ExtendAir rc4005, Terminal, UPC
206246	ExtremeAir rc18205 Terminal, FCC
206318	ExtendAir rc24005 (3x10/100BaseT)
206337	EX-5/6-DS3 GigE LB TYPE I, Terminal, Exalt
206345	ExploreAir rc28105 Terminal
206369	ExtendAir rc38000 (1x10/100BaseT) Terminal, ETSI
206412	EX-11i-OC3-GigE 29 dBm 1.5+0 terminal
206493	ExploreAir rc42100 (1xPoE) Terminal
206551	ExploreAir rc28105 Terminal
206584	ExploreAir LR rc07150
206617	ExploreAir rc31005 (LMDS 3xGbE), Terminal, Exalt
206618	ExploreAir rc31010 (LMDS PoE+4xT1/E1), Terminal
206723	ExploreAir LR rc11150 2 x 10/100/1000BaseT
206997	Power Injector, PoE, Half RU, Gbe, 48V, 2.5A Input, w/o Surge Protection
206999	ExtremeAir/ExploreAirHP/LR +24VDC 1/2RU DC PWR kit
207030	TERMINAL, BASE, EXTENDAIR RC150XX, ETSI
207036	Power Injector, PoE, 1RU, 48VDC Input, w/o Surge Protection
207125	ExploreAir rc11105 HP Terminal, FCC/ETS
207132	ExploreAir rc11110 HP Terminal, FCC/ETSI
207132	ExploreAir rc11110 High-power 11 GHz FCC & ITU/ETSI, TR490/500 MHz, PoE+4xT1/E1
207209	ExploreAir 6 GHz, rc6150 6L, Terminal
207213	ExploreAir 6 GHz, rc6150 6U/6M (1xPoE, SFP, DC Type N), Terminal
207321	TRANSFORMER, GIGABIT ETHERNET,PoE,plus IEEE802.3at,-40 to 85C,RoHS
207409	TERMINAL, BASE, EXPLOREAIR HP RC111XX
207433	TERMINAL, BASE, EXPLOREAIR RC111XX, ETSI / FCC
207531	TERMINAL, BASE, EXPLOREAIR RC181XX, FCC
207660	TERMINAL, BASE, EXTREMEAIR RC112XX, FCC
207805	ExtendAir eMIMO 5 Base Level
207927	ExtendAir eMIMO r5050 FCC terminal
207928	ExtendAir eMIMO rc5050 FCC Terminal, Connectorized
208042	ExtendAir G2 rc15020 ITU/ETSI
208219	ExtendAir G2 AC Power Kit for NAM
208220	POWER INJECTOR, 36-72V DC INPUT, 33.6W, GbE PoE
208222	ExtendAir G2 / ExpandAir AC Power Kit
208391	11 GHz G2 Diplexer
208400	ExtendAir r5005 -T (3x10/100BaseT), TERMINAL
208513	ExpandAir r5600, Terminal
208658	ExtendAir eMIMO r5050 FCC Terminal
208665	ExtendAir eMIMO rc5050 World Terminal, Connectorized
208791	ExploreAir LR rc7150
208798	ExtendAirG2 rc11020
208827	EXTENDAIR R5005 -A (3x10/100BaseT), TERMINAL
208834	ExtendAir 5GHz Triband Outdoor Radio, 27Mbps, Expands to 160Mbps, 3x100BT ports, Connectorized



43250 Christy Street
 Fremont, CA 94538
 Phone: +1 (510) 498-7900
sales@starmicrowave.com

PART NUMBER	DESCRIPTION
208870	ExtendAirG2 rc18020
208873	Connector, BNC Terminator, Male, 50 Ohms
208958	18GHz ExtendAir G2
208960	Extendair G2 rc38020, Terminal
208961	ExtendAir G2 rc18020
209028	ExtendAir G2 rc11020 FCC/ITU
209029	ExtendAir G2 rc13020
209030	ExtendAirG2 rc23020 ITU/ETSI PoE TR1232
209230	Terminal, ExpandAir rc5600 Hub
209251	ExtendAir G2 rc07020 7 GHz ITU/ETSI
209252	ExtendAir G2 rc08020
209318	ExpandAir rc5600 Hub, FCC
209320	Terminal, ExpandAir rc5600 Hub, World
209321	ExpandAir r5600 Hub 9/17 dBi
209324	Terminal, ExpandAir rc5600 Sub
209326	Terminal, ExpandAir rc5600 Sub, World
209327	ExpandAir r5600 Sub 23 dBi
209329	Terminal, ExpandAir r5600 Sub 23 dBi, World
209851	ExtendAir G2 rc24020 24 GHz FCC/ITU/ETSI
209871	ExpandAir r5661S Sub
210658	EX-5r-c V2 Terminal